## **INSTALLATION GUIDE**

ILLUMINATED MIRROR 燈鏡安裝說明(110V)



## 1. Ensure that the domestic electrical mains supply to which the Mirror connected is turned off.

- 必須確保與鏡子連接的主要供應電源是關閉的.
- 2. Using a spirit level draw a horizontal line on appropriate position and mark two points that are exactly 240mm apart.
- 在適當位置的水平線上:距離240MM的地方,用鉛筆標示兩個鑽孔位置點.

3. Using a 6mm masonry drill, accurately drill the holes in the marked positions to a depth of 50mm. If drilling through tiles, please pre-drill using a ceramic drill bit.

當安裝在水泥牆,使用1/4英吋鑽頭,鑽孔深度5公分.

4. Insert the wall plugs to the surface of the wall. If fitting to a tiled surface, the wall plugs should be inserted below the surface of the tile to avoid cracking.

崁入塑膠塞並使之齊平於牆面,遇有磁磚時塑膠塞要低於磁磚,以免螺絲鎖緊時磁磚爆裂.

5. Fix Bracket on wall and check level.

安裝背板固定,並確認水平.

6. Connect the flexible mains supply cable on the back of the mirror to the domestic electrical mains supply ensuring that the Live (Black) conductor is connected to the Live on the domestic electrical mains supply, the Neutral (White) conductor is connected to the Neutral on the domestic electrical mains supply and the Earth (Green) conductor is connected to the Earth/Ground on the domestic electrical mains supply. 連接背部電源線, 線線調連接地線.

7. Ensure that the light units are both switched on before hanging the mirror.

確認背後電燈個別開關已開啓.

NOTE: 1. Replace T5 13W TUBE by inserting into light unit and carefully twisting through 90 to lock into place.

- 更換燈管時,將 T5 13W的燈管插入燈座內,旋轉 90°以卡住燈管.
  - 2. Only use T5 FLUORESCENT 13W TUBE. TUBE LENGTH 515MM (WITH PINS 530MM). 使用燈管規格, T5 13W日光燈管長度為515mm, 加上兩邊接頭為530mm.

## FIXING CONTENTS <sub>組配件內容</sub>



JUSTIME I5時代 ST SHENG TAI BRASSWARE CO., LTD.

www.justime.com

PU68-41-STY1<sup>-</sup> MADE IN TAIWAN