INSTALLATION INSTRUCTIONS

6873 安裝說明

- Use Bracket as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置,畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert Plastic Anchors. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於牆面.
- Attach Bracket to wall with Wall Screws. 將固定鐵片以螺絲鎖在牆面上.
- Locate the Main Part on the Bracket and secure with Set Screw. 在固定鐵片上面掛住產品本體.並以螺絲起子由下方鎖緊埋頭螺絲,完成安裝程序.



JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.



www.justime.com

PU68-73-ST00 MADE IN TAIWAN

INSTALLATION INSTRUCTIONS

6873 安裝說明

- Use Bracket as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert Plastic Anchors. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於牆面.
- 3. Attach Bracket to wall with Wall Screws.
- 3. Attach Bracket to Wall With Wall Screws. 將固定鐵片以螺絲鎖在牆面上.
- Locate the Main Part on the Bracket and secure with Set Screw. 在固定鐵片上面掛住產品本體,並以螺絲起子由下方鎖聚埋頭螺絲,完成安裝程序.



