## **MOUNTING INSTRUCTIONS** 裝 說 明

安 6802

1.) Use Bracket as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置,畫上記號.

2.) Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 當安裝在水泥牆,使用1/4英吋鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於 牆面.

- 3.) Attach Bracket to wall with Wall Screws. 將固定鐵片以螺絲鎖在牆面上.
- 4.) Locate the Main Part on the Bracket and secure with Set Screw 在固定鐵片上面掛住產品本體,並以螺絲起子由下方鎖緊埋頭螺絲,完成安裝 程序.





JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.



6802 安裝 說明

- 1.) Use **Bracket** as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置,畫上記號.
- 2.) Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert Plastic Anchors. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於 牆面.
- 3.) Attach Bracket to wall with Wall Screws. 將固定鐵片以螺絲鎖在牆面上.
- 4.) Locate the Main Part on the Bracket and secure with Set Screw . 在固定鐵片上面掛住產品本體,並以螺絲起子由下方鎖緊埋頭螺絲,完成安裝 程序



JUSTILLE | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.

www.justime.com

PU68-02-ST00 <sup>□</sup> MADE IN TAIWAN 090409



090409

www.justime.com

PU68-02-ST00 F